

Create the beautiful  
authentic feel of  
exposed brick with

# Bricktile™

## Fitting Instructions

### Surface Preparation

- Remove any loose paintwork, and repair any flaking surfaces.
- Dust down the prepared surface and remove any grease or dirt.
- Dampen absorbent surfaces with a water spray, or damp brush.

### Adhesive

- Mix your heavy duty tile adhesive, Such as Ceresit CM18 or Ardex X7GPlus to the desired consistency.
- Apply the adhesive to the surface at a depth of 3-4mm to an area you can cover quickly (5-10 tile area.)

### Fitting the brick tiles

- From the bottom upwards, adhere your brick slips to the desired surface, cutting in where necessary.
- Adhere your second course, using your desired bond pattern and using 10mm spacers between courses.
- Complete the works whilst the adhesive is still workable.

### Pointing

- Once the adhesive is cured point the brick slips using sand cement mortar, or a gun-able mortar such as Easipoint.
- Once mortar is touch dry complete desired pointing effect with a steel pointing tool or similar finishing equipment.

If you have any queries please contact our technical department:

01342 813866

**IBSTOCK** **KEVINGTON**

BUILDING COMPONENTS & SPECIALS RANGE